



BRG Wi-Fi Digital Clock Configuration and Operation

Updated:03-01-2019

Power on only one unconfigured clock at a time. Using a smart phone, go to Settings > Wi-Fi and search for a Wi-Fi device with the name "nwts-conf" and click on it. If the device does not appear in the list, refresh the list again. If the phone ask for a password, enter "config-me".

Select the desired network from the list provided on the phone, then enter the password for the selected network and Save.

To display the network IP and MAC addresses, momentarily press the Up and Down button at the same time, or press and hold the Mode button until the display counts up to 9, then release. If the addresses don't display, wait another 15 seconds and try again. Enter the IP into a web browser to access the Wi-Fi configuration web page.

Use the clock Mode configuration commands to configure time zone offsets and daylight saving time. **DO NOT CHANGE TIME ZONE OFFSETS OR DAYLIGHT SAVING RULES USING THE WEB BROWSER.** The instructions are available in the user manual.

Clock Commands:

To enable the Wi-Fi Access Point use clock Mode 50-10

To restore factory defaults and enable the Wi-Fi Access Point, use clock Mode 50-11.